

Archibus Space Console

- [Space Console Overview](#)
 - [General Navigation](#)
 - [Retrieving Floor Plans and Data](#)
 - [Displaying Floor Plans and Data](#)
 - [Reviewing Data](#)
 - [Exporting Floor Plans to PDF](#)

Use the table of contents hyperlinks to navigate within the module

Space Console Overview

The Space Console is a multi-faceted tool for viewing your space and occupancy. With the Space Console, you can:

- Find a set of floors or rooms that meet certain criteria
- Highlight floor plans by department assignment and room type
- Display PI Assignments on floor plans
- Display Shared Spaces by Department on floor plans
- Export floor plans to PDF

General Navigation

1. Click on the **Space Console** link in the Tasks bucket on the home page.
2. You can Toggle between **Space mode** and **Occupancy mode** (to be discussed later in the presentation).
3. In the **Space mode**, search for floor plans and data by using the **Locations filter panel**.
4. Select floor plans to display the **Floor Plan panel**.
5. On the right side of the screen, the Space Console displays the floor plans that you select.
6. The **Floor Plan ribbon** with options for controlling the highlights and labels for the floor plan is located above the floor plan and also offers commands for exporting the floor plans.
7. Toggle between the **asset tabs** (Organizations, Room Categories and Rooms) to display space data.

The screenshot displays the Archibus Space Management System interface. At the top, a 'Tasks' bucket (1) contains 'Space Update Form', 'View All Space Requests', and 'Space Console'. Below this, the 'Space Console' header (2) features 'Space' and 'Occupancy' modes. A 'Locations' filter panel (3) is visible, with a 'Filter' button (4). The main area shows a floor plan (5) with room numbers and a ribbon (6) for highlights and labels. At the bottom, 'Organizations', 'Room Categories', and 'Rooms' tabs (7) are shown.

Building	Floor	Drawing	Room Area ft ²	Capacity	Occupancy	Room Count	
<input type="checkbox"/>	HQ	01	hq01	3,441.93	0	0	23
<input type="checkbox"/>	HQ	11	hq11	3,433.89	21	0	21
<input type="checkbox"/>	HQ	15	hq15	5,373.24	24	20	44
<input checked="" type="checkbox"/>	HQ	17	hq17	5,287.06	44	38	49
<input type="checkbox"/>	HQ	18	hq18	5,385.07	23	6	43
<input type="checkbox"/>	HQ	19	hq19	5,764.59	20	22	44
<input type="checkbox"/>	HQ	B1	hqb1	6,428.73	0	0	6

Division/Department	Name	Total Area ft ²	Room Count	Legend	Edit
▶ [Unassigned]		25,094.08	162		
▶ ELECTRONIC SYS.	Electronic Systems	2,252.48	17		Assign
▶ EXECUTIVE	Executive	3,800.81	23		Assign
▶ FACILITIES	Facilities	2,459.11	17		Assign

Retrieving Floor Plans & Data

1. Use the **Locations Filter panel** to restrict your search to a specific building and floor. The Location Filter offers several fields that allow you to enter your search criteria, such as Department, Floor, and Employee.
2. Note: The Vacant only and Unassigned radio button features are not being used by UCSF-Campus (Medical Center does use them). If selected for Campus occupied buildings, these will not return data.

TIPS:

- All space at UCSF is owned by the Chancellor. Space that is not currently *assigned* to a department, may be found in the Business Unit of “CHANCELLOR.”
- To identify CHANCELLOR space in the Floor Plan panel, select Business Unit in the Highlights drop-down.

The screenshot displays the Space Console interface. On the left, the 'Locations' filter panel is active, with a circled '1' next to the 'Locations' header and a circled '2' next to the 'Vacant only' checkbox. Below the filter panel is a table of room data. The table has columns for Building, Floor, Drawing, Room Area ft², Capacity, Occupancy, and Room Count. The row for HQ 17 hq17 is highlighted in yellow. Below the table, there are summary statistics: 35,114.51, 132, 86, and 230. At the bottom, there are tabs for Organizations, Room Categories, and Rooms. The 'Rooms' tab is selected, showing a table with columns for Division/Department, Name, Total Area ft², Room Count, Legend, and Edit. The 'Restrict to HQ' checkbox is checked. On the right, a floor plan view is shown with various rooms numbered and color-coded. The floor plan is labeled 'HQ17' at the bottom.

Building	Floor	Drawing	Room Area ft ²	Capacity	Occupancy	Room Count	
<input type="checkbox"/>	HQ	01	hq01	3,441.93	0	0	23
<input type="checkbox"/>	HQ	11	hq11	3,433.89	21	0	21
<input type="checkbox"/>	HQ	15	hq15	5,373.24	24	20	44
<input checked="" type="checkbox"/>	HQ	17	hq17	5,287.06	44	38	49
<input type="checkbox"/>	HQ	18	hq18	5,385.07	23	6	43
<input type="checkbox"/>	HQ	19	hq19	5,764.59	20	22	44
<input type="checkbox"/>	HQ	B1	hqb1	6,428.73	0	0	6

Division/Department	Name	Total Area ft ²	Room Count	Legend	Edit
▷ [Unassigned]		25,094.08	162		
▷ ELECTRONIC SYS.	Electronic Systems	2,252.48	17		Assign
▷ EXECUTIVE	Executive	3,800.81	23		Assign
▷ FACILITIES	Facilities	2,459.11	17		Assign

Displaying Floor Plans & Data

- If you'd like to add or remove the columns of information displayed for the location, use the **gear cog icon** located at the top of the Space Console to access the **Select Fields** window.
- Click on the **check box** next to a building and floor. The floor plan is displayed to the right of the form. The system automatically highlights the floor plan by division. If you would like to view multiple floor plans at a time, click on the check box next to additional rows to view multiple floors.

The screenshot displays the Archibus Space Console interface. On the left, there is a 'Locations' table with columns for Building, Floor, Drawing, Room Area, Capacity, Occupancy, and Room Count. The row for Building 2450, Floor 03 is selected. Below the table, there are tabs for 'Organizations', 'Room Categories', and 'Rooms'. A floor plan is displayed on the right side of the console, corresponding to the selected location. The floor plan is color-coded by division. A red arrow labeled '3' points to a gear icon in the table's header area, and another red arrow labeled '4' points to a check box in the table's first column.

Building	Floor	Drawing	Room Area ft ²	Capacity	Occupancy	Room Count
<input type="checkbox"/>	2450	01	2450_01	72,213.21	0	184
<input type="checkbox"/>	2450	02	2450_02	92,363.09	0	191
<input checked="" type="checkbox"/>	2450	03	2450_03	91,875.98	0	447
<input type="checkbox"/>	2450	04	2450_04	91,345.18	0	703
			550,017.87	0	1,780	1,780

Division/Department	Name	Total Area ft ²	Room Count	Legend
111061	M_Anthro, History, Social Med	3,421.21	20	[Green Box]
112100	M_Epidemiology &...	2,749.05	11	[Orange Box]

Reviewing Data

1. The **Space mode asset section** displays a series of tabs showing employee, organization, room category, and room information. Simply click each tab to toggle between them.
2. The list of data presented in the tabs is restricted to your selection if the Restrict box is checked. Uncheck the box to see all data for the building.
3. In addition to displaying data, the tabs offer:
 - the Gear cog icon for changing the fields displayed in the tab
 - a button for exporting to Word and Excel

The screenshot shows the Space Console interface. The top navigation bar includes 'Space' and 'Occupancy' tabs. The main content area is divided into two sections: a summary table and a detailed room list.

Summary Table:

Building	Floor	Drawing	Room Area ft ²	Capacity	Occupancy	Room Count
2415	01	2415_01	44,417.12	0	108	136
2415	02	2415_02	43,121.11	0	45	140
2415	03	2415_03	38,870.23	0	72	154
			301,990.03	0	625	856

Room List Table:

Building	Floor	Room	Room Area ft ²	Is Hotelable?	Occupancy Count	Room Type
2415	05	560	1,699.95	No	11	ADMIN OFFICE
2415	05	560A	144.83	No	0	CONFERENCE RM
2415	05	560B	117.35	No	1	ADMIN OFFICE
			1,962.13			

Annotations:

- 1:** Points to the 'Organizations', 'Room Categories', and 'Rooms' tabs.
- 2:** Points to the 'Restrict to 2415' checkbox.
- 3:** Points to the gear icon and the export buttons (Word and Excel).

The right side of the interface shows a floor plan for building 2415, with rooms color-coded and labeled with their IDs (e.g., 500A, 500B, 500C).

Exporting Floor Plans to PDF

1. To download a floor plan wherever you see the Export icon in the **Space Mode** or **Occupancy Mode**. Click on the Export icon and select **Generate PDF of Floors in Location List**

The screenshot shows the Space Console interface. On the left, there is a 'Locations' table with columns for Building, Floor, Drawing, Room Area, Capacity, Occupancy, and Room Count. The row for Building 2415, Floor 05 is selected. On the right, a floor plan view shows various rooms. A red arrow labeled '1' points to the 'Export' icon in the top right corner. A dropdown menu is open, showing the option 'Generate PDF of Floors in Location List' highlighted in red, with a red circle labeled '2' around it. Other options in the menu include 'Generate Ad Hoc PDF Report', 'Generate DOCX of Floors in Location List', and 'Export What You See to DOCX'.

Building	Floor	Drawing	Room Area ft ²	Capacity	Occupancy	Room Ct
2415	03	2415_03	38,870.23	0	73	
2415	04	2415_04	42,086.07	0	77	
2415	05	2415_05	42,684.52	0	122	
			281,028.84	0	510	

2. Note: The PDF download will include ALL floors that are listed in the Location filter panel.